

# RedLINK™ Accessories

## REM5000 Portable Comfort Control



Use the Portable Comfort Control anywhere in the home to experience a new level of comfort and convenience. Works in both zoned and non-zoned applications.

- Powered by RedLINK™ reliability
- No interference with other wireless devices in the home
- Works with compatible RedLINK™ enabled thermostats and accessories
- Installs in minutes
- Touchscreen interface with backlit display
- Can display outdoor temperature and humidity
- Built-in pager with an audible noise helps locate the device in the home
- Screen-lock feature helps prevent accidental changes
- 1 year battery life
- 2 month low battery warning
- In Non-Zoned Applications: Bring it with you anywhere in the home to sense and control temperature from the room that you are in
- In Zoned Applications: View and adjust all RedLINK™ enabled thermostats from a single control
- Controls up to 16 thermostats

**Applications:** Zoned and Non-Zoned Applications

**Changeover:** Auto or Manual

**Differential Temperature:** ± 1°F (±0.5°C)

**Operating Temperature Range:** 32°F to 120°F (0°C to 48.9°C)

**Operating Humidity Range (% RH):** 5 to 90% RH, non-condensing

**Power Method:** Battery

**Dimensions:** 6 1/4 in. high x 3 1/8 in. wide x 1 5/8 in. deep (159 mm high x 79 mm wide x 41 mm deep)

**Sensor Element:** Thermistor

**Used With:** RedLINK™ enabled thermostats and accessories

**Comments:** Portable Comfort Control is also available in kits.

Material Number	Description
REM5000R1001/U	Use the Personal Comfort Station™ anywhere in the home to experience a new level of comfort and convenience. Works in both zoned and non-zoned applications.

## Wireless Adapter



Wireless Adapters allows easy addition of RedLINK™ enabled thermostats to TrueZONE™ systems. Use with a RedLINK™-enabled TrueSTEAM™ Humidification System to communicate & control humidity. It also controls dehumidifiers like the Honeywell TrueDRY™.

- Powered by RedLINK™ reliability.
- No interference with other wireless devices in the home.
- Communicates with Wireless Outdoor Sensor to automatically control humidity.

**Terminal Designations:** A, B, C, D

**Mounting:** Mount Wireless Adapter on wall near HVAC equipment or on the duct.

**Color:** Gray

**Operating Temperature Range:** -40°F to 165°F (-40°C to 73.9°C)

**Operating Humidity Range (% RH):** 5 to 95% RH, non-condensing  
**Dimensions:** 5 9/16 in. high x 4 3/8 in. wide x 1 1/4 in. deep (141 mm high x 112 mm wide x 32 mm deep)

**Operation:** One adapter per zone control panel, HZ322 or HZ432 TrueZONE panel

Material Number	Description
THM4000R1000/U	Wireless Adapter allows you to easily add RedLINK™ enabled thermostats to a TrueZONE™ system without running new wires.