



HOSES HOSE FITTINGS

WELDING ACCESSORIES

HOSES: SINGLE/TWIN

Make the right connection with Uniweld's 3/16" and 1/4" hoses

Color coded twin hose sets:

Green/Oxygen; Red/Fuel.

"A", "B", and "AB" hose fittings

Twin hose available by the reel and special lengths. [Contact customer service]

HOSE SPRINGS [Part# SHLP] may be added to acetylene or LP single gas hoses by adding an (S) for spring and (SS) for two springs (one at each end) to hose Part#. Examples: H12S, H12SS/HLP14BS, HLP14BSS



OXY LP GAS 3/16" GRADE "T" TWIN HOSES

H32AT 43560	H32BT 43561	H32ABT 43562
12.5'	12.5'	12.5'
"A"	"B"	"AB"

OXY LP GAS 1/4" GRADE "T" TWIN HOSES

HT41B 43529	HT43B 43523	HT44B 43524	HT100B 43528
20'	25'	50'	100'
"B"	"B"	"B"	"B"

OXYACETYLENE 3/16" TWIN HOSES [GRADE R]

PART# UPC#	H32A 43510	H32B 43512	H32AB 43511	H31B 43509	H33A 43513	H33B 43515	H33AB 43514	H34A 43516	H34B 53517
HOSE LENGTH	12 1/2'	12 1/2'	12 1/2'	20'	25'	25'	25'	50'	50'
CONNECTION	"A"	"B"	"AB"	"B"	"A"	"B"	"AB"	"A"	"B"

1/4" TWIN HOSES [GRADE R]

PART# UPC#	H43B 43520	H44B 43521	H100B 43522
HOSE LENGTH	25'	50'	100'
CONNECTION	"B"	"B"	"B"

SINGLE 3/16" SINGLE ACETYLENE HOSES [GRADE R]

PART# UPC#	H11 43500	H11B 43501	H12 43502	H12B 43503	H13 43504	H13B 43505
HOSE LENGTH	6'	6'	12 1/2'	12 1/2'	25'	25'
CONNECTION	"A"	"B"	"A"	"B"	"A"	"B"

3/16" LP GAS SINGLE HOSES

PART# UPC#	HLP10 43530	HLP10B 43531	HLP11 43533	HLP11B 43534	HLP13 43537	HLP13B 43538	HLP14 43541	HLP14B 43542
HOSE LENGTH	3'	3'	6'	6'	25'	25'	12 1/2'	12 1/2'
CONNECTION	"A"	"B"	"A"	"B"	"A"	"B"	"A"	"B"

HOSE FITTINGS

HOSE NIPPLE

PART#	UPC#	Hose Nut to Nipple Size
HN83P	43370	3/16" "A"
HN87	43371	3/16" "B"
HN84	43372	1/4" "B"

HOSE NUT

PART#	UPC#	Hose Nut to Nipple Size
HN82A	43348	"A" RH 3/16"
HN83A	43349	"A" LH 3/16"
9059	43350	"B" RH 1/4" or 3/16"
9059-2	43351	"B" LH 1/4" or 3/16"

HOSE SPLICER (Push Type)

PART#	UPC#	Hose to Hose
H553	43373	1/4" to 1/4"
H554	43374	3/16" to 1/4"
H555	43375	3/16" to 3/16"

BRASS HOSE CLAMPS

PART#	UPC#	Hose I.D.
HC01	43376	3/16"
HC02	43377	1/4"

"A" to "B" WELDING HANDLE ADAPTOR

PART#	UPC#	Handle to Hose
F29L	43322	"A" Conn LH "B" Hose Nut LH
F29R	43324	"A" Conn RH "B" Hose Nut RH

"A" to "B" OUTLET ADAPTOR

PART#	UPC#	Regulator To Hose
F27L	43320	"A" Conn LH "B" Hose Nut LH
F27R	43321	"A" Conn RH "B" Hose Nut RH

"A" SIZE "Y" OUTLET ADAPTOR

PART#	UPC#	Inlet to Outlet
FY11XA	43332	"A" LH "A" Hose Nut LH
FY10XA	43331	"A" RH "A" Hose Nut RH

"Y" CONNECTORS W/VALVES

PART#	UPC#	Inlet to Outlet
FY10XAV	43334	"A" RH "A" Hose Nut RH
FY11XAV	43335	"A" LH "A" Hose Nut LH
FY10XV	43336	"B" RH "B" Hose Nut RH
FY11XV	43337	"B" LH "B" Hose Nut LH

"B" SIZE "Y" CONNECTORS

PART#	UPC#	Inlet to Outlet
FY11X	43330	"B" LH "B" Hose Nut LH
FY10X	43329	"B" RH "B" Hose Nut RH

HOSE COUPLING

PART#	UPC#	Hose Nut to Hose Nut
HCC40	43342	"A" LH "A" LH
HCC46	43343	"A" LH "B" LH
HCC41	43344	"A" RH "A" RH
HCC79	43345	"B" LH "B" LH
HCC47	43346	"A" RH "B" RH
HCC78	43347	"B" RH "B" RH

"A" to "B" OUTLET ADAPTOR

PART#	UPC#	Regulator To Hose
F58L	43325	"A" Conn LH "B" Hose Nut LH
F58R	43326	"A" Conn RH "B" Hose Nut RH

"B" to "A" OUTLET ADAPTOR

PART#	UPC#	Regulator To Hose
F59L	43327	"B" Conn LH "A" Hose Nut LH
F59R	43328	"B" Conn RH "A" Hose Nut RH

Additional hose fittings available. [See hose repair kits, page 104].